

PHILIPS



AMBILIGHT tv

Quick Start Guide



9000/9010/9050/9060/9080 Series



Tool needed
for assembly



43" (M4xL12) : x7
50"/55" (M4xL12) : x4
(M5xL16) : x3
65" (M4xL16) : x4
(M5xL16) : x3





(EU)





(UK)





1 43"/50"/55"





65"




2




3




A Desk Placement






B Wall Placement





A






43" (M4xL12) x3
50"/55"/65" (M5xL16) x3



43"/50"/55" (M4xL12) x4
65" (M4xL16) x4



Recommended Wall Distance



4

Get Connected



www.philips.to/smartTV

The Philips Smart TV app lets you switch channels and adjust the volume - just like a remote control.

5

Register and Support



www.philips.com/TVsupport

Register your TV, find out more, download the user manual and get support

