



PHILIPS









QP2724
QP2734
QP2824
QP2834








	①	②	③	④	⑤	⑥	⑦	⑧	⑨
QP2724/20	✓	✓		✓					✓
QP2734/20	✓	✓	✓						✓
QP2824/20	✓	✓		✓	✓	✓	✓	✓	✓
QP2834/20	✓	✓	✓		✓	✓	✓		✓
QP2724/30	✓	✓		✓			✓	✓	✓
QP2734/30	✓	✓	✓						✓
QP2734/31	✓	✓	✓						✓
QP2824/30	✓	✓		✓	✓	✓	✓	✓	✓



www.philips.com/support





FR

Cet appareil, ses accessoires, cordons et batteries se recyclent



Points de collecte sur www.quefairedemesdechets.fr

© 2023 Koninklijke Philips N.V.
All rights reserved
3000.092.1301.5 (06/02/2023)

>75 % recycled paper
>75 % papier recyclé